



Legal:

The content of this guide may not be sold, modified, or distributed in anyway without the expressed written consent of the publisher. Reprinting, copying, or any other form of distribution for commercial or non-commercial purposes is strictly prohibited and will be prosecuted.

Disclaimer:

Every attempt has been made to provide the most accurate information as possible. However, the publisher accepts no liability for any wrong information as a result of purchasing and / or reading this guide.

You can follow this guide at your own risk the publisher accepts no responsibility for any injury to any person.





Copyright © www.Construct101.com

All rights reserved

ISBN-13:

ISBN-10:

Overview





Material List

Shopping List

A shopping list is included. Since lumber can be purchased in different sizes the shopping list will vary. Study the cut list to see what will work best for you.

(material for door/window not included)

Floor

- 2 – 2×6 pressure treated – 10'
- 9 – 2×6 pressure treated – 10'
- 3 – 4×4 pressure treated – 10'
- 4 – 3/4" tongue and groove plywood – 4'x8' sheet

Walls

- 8 – 2×4 – 10'
- 28 – 2×4 – 8'

Rafters

- 6 – 2×4 – 12'
- 4 – 2×4 – 8'

Siding

- 10 – t1-11 exterior siding – 4'x8' sheet

Roof

- 7 – 2×4 – 12'
- 3 – 2×4 – 8'

Trim

- 10 – 1×4 – 8'

Hardware

- 3 1/2" galvanized nails
- 2" deck screws
- 2" galvanized finishing nails
- corrugated roofing panels
- roofing panel screws



www.Construct101.com

- 3 – door hinge
- 1 – door handle
- 1 – door latch

Cutting List

(material for door/window not included)

Floor

- 2 – 2×6 – 10'
- 9 – 2×6 – 9' 9"
- 3 – 4×4 – 10'
- 4 – 3/4" tongue and groove plywood – 4'x8' sheet (cut to size)

Walls

- 4 – 2×4 – 10'
- 8 – 2×4 – 7' 4 1/2"
- 20 – 2×4 – 5' 8 1/2"
- 4 – 2×4 – 9' 5"

Rafters

- 6 – 2×4 – 11' 10 3/8"
- 4 – 2×4 – 8' (cut to size)

Siding

- 10 – t1-11 exterior siding – 4'x8' sheet (cut to size)


Roof

- 7 – 2×4 – 12'
- 3 – 2×4 – 8' (cut to size)

Trim

- 10 – 1×4 – 8' (cut to size)


Floor



Cut two 2x6's to 10' long for the floor band. Cut nine 2x6's to 9' 9" for the floor joist. Cut three 4x4's to 10' long for the skids.

Assemble as shown on illustration above, floor joist are spaced 16" O.C., use 3 1/2" nails, nail through the bands and into the joist.


Square the floor frame by measuring diagonally until both sides measure the same.



Measure and cut to size the 3/4" tongue and groove floor deck.

Screw 2" deck screws through the plywood floor and into the floor frame.

Walls




Front Wall Frame:

Wall studs are spaced 24" O.C.

Cut two 2x4's to 10" long for the top and bottom plate. Cut eight 2x4's to 7' 4 1/2" for the wall studs.

See door and window PDF for framing details.

Use 3 1/2" nails to assemble wall frame.




Back Wall Frame:

Wall studs are spaced 24" O.C.

Cut two 2×4's to 10' long for the top and bottom plate. Cut eight 2×4's to 5' 8 1/2" for the wall studs.


Use 3 1/2" nails to assemble wall frame.



Side Wall Frame:


Cut four 2×4's to 9' 5" long for the top and bottom plate. Cut twelve 2×4's to 5' 8 1/2" for the wall studs.

Use 3 1/2" nails to assemble wall frame as shown on illustration above.




Secure the wall frames using 3 1/2" nails.

Rafters




Cut six 2×4's to 11' 10 3/8" for the rafters. Cut the ends of the rafters as shown on illustration below.


Before cutting all rafters make sure to test the first rafter for a good fit and use it as a template for cutting the remaining rafters.




Cut the bottom rafter end as shown on illustration above.



Cut the top rafter end as shown on illustration above.



Rafters are spaced out 24" O.C., install using 3 1/2" nails.



Measure and cut the top wall studs for the side walls to size, notch around rafters and install using 3 1/2" nails.

Cut 2x4 blocking to size and install between rafters using 3 1/2" nails.

Siding



Measure and cut the t1-11 exterior siding to size, notch front and back siding around rafters. Install siding using 2" finishing nails.

Cut door and window opening, see door and window PDF details.

Roof



Cut seven 2×4's to 12' long for the purlins. Install purlins as shown on illustration above using 3 1/2" nails.



Measure and cut 2×4 blocking and install between the purlins using 3 1/2" nails



Install the metal corrugated roofing panels

Door



Install door.

Trim



Measure and cut 1×4's to size for the corner and window trim. Install the 1×4 trim using 2" finishing nails.